ALWAYS

CHOOSE SMART

LUMILIFE

ALWAYS CHOOSE SMART

LUMILIFE

ALWAYS CHOOSE SMART















CONTENTS

Crystal Series----------01

Satin Metal Series----------05

Lace Series---------- 09

Titanium Aluminium Series----------15

Genuine Leather Series---------- 19

Mirror Series---------- 23

Wooden Series----------27

Palace Series----------31

Bronze Series---------- 35

PC Series---------- ----------39

Function Parts---------- 41

Crystal Series

Exquisite workmanship results in a translucent, glittering finish on a seiko carved face. Each procedure is carefully orchestrated to provide a more reliable, more solid piece.

Contemporary pure crystal handicrafts that will provide an elegant finish to your interior design.




PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**15B11BY** 1 Gang 1 Way Switch **15B11ABY** 1 Gang 2 Way Switch		**15B12BY** 2 Gang 1 Way Switch **15B12ABY** 2 Gang 2 Way Switch
	**15B13BY** 3 Gang 1 Way Switch **15B13ABY** 3 Gang 2 Way Switch		**15B14BY** Door Bell
	**15X15HY** TVOutlet		**15X16HY** TEL Outlet

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**15X17HY** PC Outlet		**15X18HY** 3 Pin Socket
	**15H18HY** Double TEL Outlet		**15H18HY** Double PC Outlet
	**15H19HY** Double TEL+PC Outlet		**15B11B** 1 Gang 1 Way Switch **15B11AB** 1 Gang 2 Way Switch
	**15B12B** **2** Gang 1 Way Switch **15B12AB** 2 Gang 2 Way Switch		**15B13B** **3** Gang 1 Way Switch **15B13AB** 3 Gang 2 Way Switch
	**15B14B** **4** Gang 1 Way Switch **15B14AB** 4 Gang 2 Way Switch		**15B16B** **20A** Switch **15B17AB** 45A Switch
	**15B58B** Single Black **15B59AB** Double Blank		**15B72B** FUSED
	**15B61B** 13A Socket		**15B25B** 13A Switched Socket
	**15B26B** 13A Switched Socket with neon		**15B62B** 15A Socket
	**15B27B** 15A Switched Socket		**15B28B** 15A Switched Socket with neon
	**15B29B** European Socket		**15B30B** French Socket

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**15B23B** Multi-Function Switched Socket		**15B24B** Multi-Function Switched Socket with neon
	**15B71B** Double USB Charger +Multi-Function Socket		**15B19B** Double 2 Pin Socket
	**15B20B** 1G1W+2Pin **15B20AB** 1G2W+2Pin		**15B21B** 2G1W+2Pin **15B21AB** 2G2W+2Pin
	**15B70B** Double USB Charger +13A Socket		
	**15H31H** Dimmer Speed		**15H32H** Dimmer Light
	**15H60H** Dimmer Voice		**15H53H** Light Control
	**15H54H** Touch Switch		**15H55H** Emergency
	**15H56H** Shaver Socket		**15H57H** Card-Insert
	**15H15H** Door bell Switch		**15H63** Corner Light

146 TYPE


PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**15B66B** Double 13A Switched Socket		**15B67B** Double 13A Switched Socket With Neon
	**15J68J** Double Multi-Function Switched Socket		**15J69J** Double Multi-Function Switched Socket With Neon
	**15J73J** Double European Socket		**15J74J** FUSED+Double USB Charger and Multi-Function Socket
	**15J38H** 5Pin+Double USB		**15J43H** Kitchen Switch







Satin Metal Series

Particular attention is paid to the selection and quality of material and subsequent manufacturing、surface electroplating、bronze coloring、satin surface、anti fing--erprint、spray painting.
A stunning modern crisp finish to your interior deco.

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**26Y11HY** 1 Gang 1 Way Switch **26Y11AHY** 1 Gang 2 Way Switch		**26Y12HY** 2 Gang 1 Way Switch **26Y12AHY** 2 Gang 2 Way Switch
	**26Y13HY** 3 Gang 1 Way Switch **26Y13AHY** 3 Gang 2 Way Switch		**26Y14HY** Doorbell Switch
	**26J15HY** TV Outlet		**26J16HY** TEL Outlet
	**26J17HY** PC Outlet		**26J18HY** 3 Pin Socket
	**26J19HY** Double TEL Outlet		**26J20HY** Double PC Outlet
	**26J21HY** TEL+ PC Outlet		**26Y11H** 1 Gang 1 Way Switch **26Y11AH** 1 Gang 2 Way Switch
	**26Y12H** 2 Gang 1 Way Switch **26Y12AH** 2 Gang 2 Way Switch		**26Y13H** 3 Gang 1 Way Switch **26Y13AH** 3 Gang 2 Way Switch
	**26Y14H** 4 Gang 1 Way Switch **26Y14AH** 4 Gang 2 Way Switch		**26Y16H** 20A Switch **26Y17H** 45A Switch
	**26Y58H** Single Blank **26Y59H** Double Blank		**26Y72H** FUSED
	**26Y29H** European Socket		**26Y30H** French Socket

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**26Y61H** 13A Socket		**26Y25H** 13A Switched Socket
	**26Y26H** 13A Switched Socket with neon		**26Y62H** 15A Socket
	**26Y27H** 15A Switched Socket		**26Y28H** 15A Switched Socket with neon
	**26Y23H** Multi-Function Socket		**26Y24H** Multi-Function Switched Socket
	**26Y22H** 5 Pin Socket		**26Y19H** Double 2 Pin Socket
	**26Y20H** 1G1W+2Pin **26Y20AH** 1G2W+2Pin		**26Y21H** 2G1W+2Pin **26Y21AH** 2G2W+2Pin
	**26Y70H** Double USB Charger +13A Socket		**26Y71H** Double USB Charger +Multi-Function Socket
	**26Y37H** USB+2Pin		**26Y34H** Double USB
	**26Y35H** 1G1W+USB **26Y35AH** 1G2W+USB		**26Y36H** 2G1W+USB **26Y36AH** 2G2W+USB
	**26Y46H** TEL Outlet		**26Y47H** PC Outlet

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**26Y51H** Double TEL Outlet		**26Y50H** Double TEL Outlet
	**26Y49H** TV+PC Outlet		**26Y48H** TV+TEL Outlet
	**26Y52H** PC+TEL Outlet		**26Y44H** TV Outlet
	**26Y45H** Satllet Outlet		**26J31H** Dimmer Speed
	**26J32H** Dimmer Light		**26J60H** Dimmer Voice
	**26J53H** Voice Light Control		**26J54H** Touch Switch
	**26J55H** Emergency		**26J56H** Shaver Socket
	**26J15H** Doorbell Switch		**26J57H** Card-Insert
	**26J67H** Double 13A Switched Socket With Neon		**26J69H** Double Multi-Function Switched Socket With Neon
	**26J43H** Kitchen Switch		**26J76H** Double French Socket


Lace Series

With elegant
A creative uses relievo board
We are never tired
Only to meet with the taste of dream







PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**32Y11H** 1 Gang 1 Way Switch **32Y11AH** 1 Gang 2 Way Switch		**32Y12H** 2 Gang 1 Way Switch **32Y12AH** 2 Gang 2 Way Switch
	**32Y13H** 3 Gang 1 Way Switch **32Y13AH** 3 Gang 2 Way Switch		**32Y14H** 4 Gang 1 Way Switch **32Y14AH** 4 Gang 2 Way Switch
	**32Y16H** 20A Switch **32Y17H** 45A Switch		**32Y58H** Single Blank **32Y59H** Double Blank
	**32Y72H** FUSED		**32Y61H** 13A Socket
	**32Y25B** 13A Switched Socket		**32Y26B** 13A Switched Socket with neon
	**32Y62H** 15A Socket		**32Y27B** 15A Switched Socket
	**32Y28B** 15A Switched Socket with neon		**32Y29B** European Socket
	**32Y30B** French Socket		**32Y23B4** Multi-Function Socket
	32Y24B Multi-Function Switched Socket		**32Y22B** 5 Pin Socket

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**32Y19B** Double 2 Pin Socket		**32Y20B** 1G1W+2Pin **32Y20AB** 1G2W+2Pin
	**32Y21B** 2G1W+2Pin **32Y21AB** 2G2W+2Pin		**32Y70B** Double USB Charger +13A Socket
	**32Y71B** Double USB Charger +Multi-Function Socket		**32Y37H** USB+2Pin
	**32Y34H** Double USB		**32Y35H** 1G1W+USB **32Y35AH** 1G2W+USB
	**32Y36H** 2G1W+USB **32Y36AH** 2G2W+USB		**32Y46H** TEL Outlet
	**32Y47H** PC Outlet		**32Y50H** Double TEL Outlet
	**32T51H** Double PC Outlet		**32Y52H** TV+PC Outlet
	**32Y48H** TV+TEL Outlet		**32Y49H** TV+TEL Outlet
	**32Y44H** TV Outlet		**32Y45H** Satllet Outlet

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**32Y31H** Dimmer Speed		**32Y32H** Dimmer Light
	**32Y60H** Dimmer Voice		**32Y53H** Voice Light Conrol
	**32Y54H** Touch Switch		**32Y55H** Emergency
	**32Y56H** Shaver Socket		**32Y57H** Card-Insert
	**32Y15H** Doorbell Switch		**32Y61** Corner Light
	**32H66H** Double 13A Switched Socket		**32H67H** Double 13A Switched Socket With Neon
	**32H68H** Double Multi-Function Switched Socket		**32H69H** Double Multi-Function Switched Socket With Neon
	**32H43H** Kitchen Switch		**32H38H** 5Pin+Double USB
	**32B76H** Double French Socket		**32B75H** FUSED+Double USB Charger and 13A Socket



Titanium Aluminium Series

Made of 4mm tianium aluminium, Antioxidant modern finish,
Anti-microbial treatment.

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**27X11H** 1 Gang 1 Way Switch **27X11AH** 1 Gang 2 Way Switch		**27X12H** 2 Gang 1 Way Switch **27X12AH** 2 Gang 2 Way Switch
	**27X13H** 3 Gang 1 Way Switch **27X13AH** 3 Gang 2 Way Switch		**27X14H** 4 Gang 1 Way Switch **27X14AH** 4 Gang 2 Way Switch
	**27X16H** 20A Switch **327X17H** 45A Switch		**27X58H** Single Blank **27X59H** Double Blank
	**27X72H** FUSED		**27X61H** 13A Socket
	**27X25H** 13A Switched Socket		**27X26H** 13A Switched Socket with neon
	**27X62H** 15A Socket		**27X27H** 15A Switched Socket
	**27X28H** 15A Switched Socket with neon		**27X29H** European Socket
	**27X23H** Multi-Function Socket		**27X30H** French Socket

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**27X24H** Multi-Function Switched Socket		**27X22H** 5 Pin Socket
	**27X19H** Double 2 Pin Socket		**2 Y20H** 1G1W+2Pin **7** **2 Y20AH** 1G2W+2Pin
	**2 Y21H** 2G1W+2Pin **7** **2 Y21AH** 2G2W+2Pin		**27X70B** Double USB Charger +13A Socket
	**27X71B** Double USB Charger +Multi-Function Socket		**27X37H** USB+2Pin
	**27X34H** Double USB		**27X35H** 1G1W+USB **27X35AH** 1G2W+USB
	**27X36H** 2G1W+USB **27X36AH** 2G2W+USB		**27X46H** TEL Outlet
	**27X47H** PC Outlet		**27X50H** Double TEL Outlet
	**27X51H** Double PC Outlet		**27X49H** TV+PC Outlet
	**27X48H** TV+TEL Outlet		**27X52H** PC+TEL Outlet

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**27X44H** TV Outlet		**27X45H** Satllet Outlet
	**27X31H** Dimmer Speed		**27X32H** Dimmer Light
	**27X60H** Dimmer Voice		**27X53H** Voice Light Conrol
	**327X54H** Touch Switch		**27X55H** Emergency
	**27X56H** Shaver Socket		**27X57H** Card-Insert
	**27X15H** Doorbell Switch		**27X61H** Corner Light
	**27C76H** Double French Socket		**27C42H** Double Multi-function Switched Socket with LED
	**27C75H** FUSED+Double USB Charger and 13A Socket		**27C40H** Double 13A Switched Socke with LED
	**27C38H** 5Pin+Double USB		**27C43H** Kitchen Switch

Genuine Leather Series

Adopt nature - genuine leather in pearl fishskin and goat leather.
A premium luxury look and feel to compliment your interior design






LUMILIFE
ALWAYS CHOOSE SMART

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**24E11HY** 1 Gang 1Way Switch **24E11AHY** 1 Gang 2 Way Switch		**24E12HY** 2 Gang 1Way Switch **24E12AHY** 2 Gang 2 Way Switch
	**24E13HY** 3 Gang 1Way Switch **24E13AHY** 3 Gang 2 Way Switch		**24E14HY** Doorbell Switch
	**24E11H** 1 Gang 1 Way Switch **24E11AH** 1 Gang 2 Way Switch		**24E12H** 2 Gang 1 Way Switch **24E12AH** 2 Gang 2 Way Switch
	**24E13H** 3 Gang 1 Way Switch **24E13AH** 3 Gang 2 Way Switch		**24E14H** 4 Gang 1 Way Switch **24E14AH** 4 Gang 2 Way Switch
	**24E16H** 20A Switch **24E17H** 45A Switch		**24E58H** Single Blank **24E59H** Double Blank
	**24E72H** FUSED		**24E61H** 13A Socket
	**24E25H** 13A Switched Socket		**24E26H** 13A Switched Socket with neon
	**24E62H** 15A Socket		**24E27H** 15A Switched Socket
	24E28H 15A Switched Socket with neon		**24E29H** European Socket

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**24E30H** French Socket		**24E23H** Multi-Function Socket
	**24E24H** Multi-Function Switched Socket		**24E22H** 5 Pin Socket
	**24E19H** Double 2 Pin Socket		**24E20H** 1G1W+2Pin **24E20AH** 1G2W+2Pin
	**24E21H** 2G1W+2Pin **24E21AH** 2G2W+2Pin		**24E70H** Double USB Charger +13A Socket
	**24E71H** Double USB Charger +Multi-Function Socket		**24E37H** USB+2Pin
	**24E34H** Double USB		**24E35H** 1G1W+USB **24E35AH** 1G2W+USB
	**24E36H** 2G1W+USB **24E36AH** 2G2W+USB		**24E46H** TEL Outlet
	**24E47H** PC Outlet		**24E51H** Double TEL Outlet
	**24E50H** Double PC Outlet		**24E52H** PC+TEL Outlet
	**24E48H** TV+TEL Outlet		**24E49H** TV+PC Outlet

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**24E45H** Satllet Outlet		**24E44H** TV Outlet
	**24E31H** Dimmer Speed		**24E32H** Dimmer Light
	**24E60H** Dimmer Voice		**24E53H** Voice Light Conrol
	**24E54H** Touch Switch		**24E55H** Emergency
	**24E56H** Shaver Socket		**24E57H** Card-Insert
	**24E15H** Doorbell Switch		**24E63** Corner Light
	**24Z66H** Double 13A Switched Socket		**24Z67H** Double 13A Switched Socket With Neon
	**24Z68H** Double Multi-Function Switched Socket		**24Z69H** Double Multi-Function Switched Socket With Neon
	**24Z76H** Double French Socket		**24Z75H** FUSED+Double USB Charger and 13A Socket
	**2438H** 5Pin+Double USB		**24Z43H** Kitchen Switch



Mirror Series


A choice of colours on high quality mirrored material: mirror black、mirror red、mirror white、mirror champagne gold etc.
High quality imported acrylic materials、surface electroplating、bronze coloring、anti-fingerprint、painting.

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**25H11HY** 1 Gang 1 Way Switch **25H11AHY** 1 Gang 2 Way Switch		**25H12HY** 2 Gang 1 Way Switch **25H12AHY** 2 Gang 2 Way Switch
	**25H13HY** 3 Gang 1 Way Switch **25H13AHY** 3 Gang 2 Way Switch		**25H14HY** Doorbell Switch
	**25B11HY** 1 Gang 1 Way Switch **25B11AHY** 1 Gang 2 Way Switch		**25B12HY** 2 Gang 1 Way Switch **25B12AHY** 2 Gang 2 Way Switch
	**25B13HY** 3 Gang 1 Way Switch **25B13AHY** 3 Gang 2 Way Switch		**25B14HY** Doorbell Switch

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**25B11B** 1 Gang 1 Way Switch **25B11AB** 1 Gang 2 Way Switch		**25B12B** 2 Gang 1 Way Switch **25B12AB** 2 Gang 2 Way Switch
	**25B13B** 3 Gang 1 Way Switch **25B13AB** 3 Gang 2 Way Switch		**25B14B** 4 Gang 1 Way Switch **25B14AB** 4 Gang 2 Way Switch
	**25B16B** 20A Switch **25B17B** 45A Switch		**25B58B** Single Blank **25B59AB** Double Blank
	**25B72B** FUSED		**25H61H** 13A Socket
	**25HH25H** 13A Switched Socket		**25H26H** 13A Switched Socket with neon
	**25H29H** European Socket		**25H62H** 15A Socket
	**25H27H** 15A Switched Socket		**25H28H** 15A Switched Socket with neon
	**25H30H** French Socket		**25H23H** Multi-Function Socket
	**25H24H** Multi-Function Switched Socket		**25H22H** 5 Pin Socket


PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**25H19H** Double 2 Pin Socket		**2 H20H** 1G1W+2Pin **2 H20AH** 1G2W+2Pin
	**25H21H** 2G1W+2Pin **25H21AH** 2G2W+2Pin		**25H70H** Double USB Charger +13A Socket
	**25H71H** Double USB Charger +Multi-Function Socket		**25H37H** USB+2Pin
	**25H34H** Double USB		**25H35H** 1G1W+USB **253H35AH** 1G2W+USB
	**25H36H** 2G1W+USB **25H36AH** 2G2W+USB		**25H46H** TEL Outlet
	**25H47H** PC Outlet		**25H50H** Double TEL Outlet
	**25H52H** PC+Tel Outlet		**25H49H** TV+PC Outlet
	**25H48H** TV+TEL Outlet		**25H51H** Double PC Outlet
	**25H44H** TV Outlet		**25H45H** Satllet Outlet

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**25J31J** Dimmer Speed		**25J32J** Dimmer Light
	**25J60J** Dimmer Voice		**25J53J** Voice Light Control
	**25J54J** Touch Switch		**25J55J** Emergency
	**25J56J** Shaver Socket		**25J57J** Card-Insert
	**25J15J** Doorbell Switch		**25J63J** Corner Light
	**25B66B** Double 13A Switched Socket		**25B67B** Double 13A Switched Socket With Neon
	**25B68B** Double Multi-Function Switched Soc		**25B69B** Double Multi-Function Switched Socket With Neon
	**25B77B** FUSED+Double USB Charger and French Socket		**25B76B** Double French Socket
	**25B75B** FUSED+Double USB Charger and 13A Socket		**25B43B** Kitchen Switch





Wooden Series

Select precious natural wood, carved log tactility
Taste the taste of natural wood, its rich flavor of the forest

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**42Y11H** 1 Gang 1 Way Switch **425H11AH** 1 Gang 2 Way Switch		**42Y12H** 2 Gang 1 Way Switch **42Y12AH** 2 Gang 2 Way Switch
	**42Y13H** 3 Gang 1 Way Switch **42Y13AH** 3 Gang 2 Way Switch		**42Y14H** 4 Gang 1 Way Switch **42Y14AH** 4 Gang 2 Way Switch
	**42Y16H** 20A Switch **42Y17H** 45A Switch		**42Y58H** Single Blank 42Y**59H** Double Blank
	**42Y72H** FUSED		**41H37H** USB+2Pin
	**41H34H** Double USB		**41H35H** 1G1W+USB **41H35AH** 1G2W+USB
	**41H36H** 2G1W+USB **41H36AH** 2G2W+USB		**41H46H** TEL Outlet
	**41H47H** PC Outlet		**41H50H** Double TEL Outlet
	**41H52H** TEL+ PC Outlet		**41H49H** TV+PC Outlet
	**41H48H** TV+TEL Outlet		**41H51H** Double PC Outlet


PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**41H44H** TV Outlet		**41H45H** Satllet Outlet
	**41Q61H** 13A Socket		**41Q25H** 13A Switched Socket
	**41Q26H** 13A Switched Socket with neon		**41Q29H** European Socket
	**41Q62H** 15A Socket		**41Q27H** 15A Switched Socket
	**41Q28H** 15A Switched Socket with neon		**41Q30H** French Socket
	**41Q23H** Multi-Function Socket		**41Q24H** Multi-Function Switched Socket
	**41Q22H** 5 Pin Socket		**41Q19H** Double 2 Pin Socket
	**41Q20H** 1G1W+2Pin **41Q20AH** 1G2W+2Pin		**41Q21H** 2G1W+2Pin **41Q21AH** 2G2W+2Pin
	**41Q70H** Double USB Charger +13A Socket		**41Q71H** Double USB Charger +Multi-Function Socket


PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**42Y31H** Dimmer Speed		**42Y32H** Dimmer Light
	**42Y60H** Dimmer Voice		**42Y53H** Voice Light Conrol
	**42Y54H** Touch Switch		**42Y55H** Emergency
	**42Y56H** Shaver Socket		**42Y57H** Card-Insert
	**42Y15H** Doorbell Switch		**42Y63** Corner Light
	**42Y66J** Double 13A Switched Socket		**42Y67J** Double 13A Switched Socket With Neon
	**42Y68J** Double Multi-Function Switched Socket		**42Y69J** Double Multi-Function Switched Socket With Neon
	**42Y77J** DoubleUSB+European Socket		**42Y74J** FUSED+Double USB Charger and Multi-Function Socket
	**42Y73J** Double European Socket		**42Y42J** Kitchen Switch






Classic Palace

Adopt pure copper,CNC carved panel.

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**55G11G** 1 Gang 1 Way Switch **55G11AG** 1 Gang 2 Way Switch		**55G12G** 2 Gang 1 Way Switch **51G12AG** 2 Gang 2 Way Switch
	**55G13G** 2 Gang 1 Way Switch **55G13AG** 2 Gang 2 Way Switch		**55G15G** Door Bell
	**53Q11HY** 1 Gang 1 Way Switch **53Q11AHY** 1 Gang 2 Way Switch		**53Q12HY** 2 Gang 1 Way Switch **53Q12AHY** 2 Gang 2 Way Switch
	**53H17HY** PC Outlet		**53H18HY** 3 Pin Socket

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**54H11J** 1 Gang 1 Way Switch **54H11AJ** 1 Gang 2 Way Switch		**54H12J** 2 Gang 1 Way Switch **54H12AJ** 2 Gang 2 Way Switch
	**54H13J** 3 Gang 1 Way Switch **54H13AJ** 3 Gang 2 Way Switch		**54H14J** 4 Gang 1 Way Switch **54H14AJ** 4 Gang 2 Way Switch
	**54H16J** 20A Switch **54H17J** 45A Switch		**54H58J** Single Blank **54H59J** Double Black
	**54H72J** FUSED		**53J61H** 13A Socket
	**53J25H** 13A Switch Socket		**53J26H** 13A Switched Socket with neon
	**53J29H** European Socket		**53J62H** 15A Socket
	**53J27H** 15A Switched Socket		**53J28H** 15A Switched Socket with neon
	**53J30H** French Socket		**53J23H** Multi-Function Socket
	**53J24H** Multi-Function Switched Socket		**53J22H** 5 Pin Socket


PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**5 Y19H** Double 2 Pin Socket		**53J20H** 1G1W+2 Pin **53J20AH** 1G2W+2 Pin
	**53J21H** 2G1W+2 Pin **53J21AH** 2G2W+2 Pin		**53J70H** Double USB Charger +13A Socket
	**53J71H** Double USB Charger +Multi-Function Socket		**51Y37H** USB+2Pin
	**51Y34H** Double USB		**51Y46H** TEL Outlet
	**51Y36H** 2G1W+USB 51Y**36AH** 2G2W+USB		**51Y35H** 1G1W+USB **51Y35AH** 1G2W+USB
	**51Y47H** PC Outlet		**51Y50H** Double TEL Outlet
	**51Y52H** TEL+ PC Outlet		**51Y49H** TV+PC Outlet
	**51Y48H** TV+TEL Outlet		**51Y51H** Double PC Outlet
	**51Y44H** TV Outlet		**51Y45H** Satllet Outlet

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**51J31H** Dimmer Speed		**51J32H** Dimmer Light
	**51J60H** Dimmer Voice		**51J53H** Voice Light Conrol
	**51J54H** Touch Switch		**51J55H** Emergency
	**51J56H** Shaver Socket		**51J57H** Card-Insert
	**51J15H** Doorbell Switch		**51J63** Corner Light
	**51O39B** Double 13A Switched Socket		**51O40B** Double 13A Switched Socke with LED
	**51O41H** Double Multi-function Switched Socket		**51O42H** Double Multi-function Switched Socket with LED
	**51O75H** FUSED+Double USB Charger and 13A Socket		**51OJ77H** Double French Socket
	**52H38H** 5Pin+Double USB		**52H43H** Kitchen Switch

Bronze Series

Copper plated zinc alloy frame creates our latest Bronze series. With big button and smooth touching,
Bronze series could be your first choice.



PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**36L11L** 1 Gang 1 Way Switch **36L11AL** 1 Gang 2 Way Switch		**36R11R** 1 Gang 1 Way Switch **36R11AR** 1 Gang 2 Way Switch
	**36J11J** 1 Gang 1 Way Switch **36J11AJ** 1 Gang 2 Way Switch		**36G11G** 1 Gang 1 Way Switch **36G11AH** 1 Gang 2 Way Switch
	**36Y16H** 20A Switch **36Y17H** 45A Switch		**36Y58H** Single Blank 36Y**59H** Double Blank

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**36L12H** 2 Gang 1 Way Switch **36L12AH** 2 Gang 2 Way Switch		**36L13B** 3 Gang 1 Way Switch **36L13AB** 3 Gang 2 Way Switch
	**36Y61H** 13A Socket		**36Y25H** 13A Switched Socket
	**36Y26H** 13A Switched Socket with neon		**36Y29H** European Socket
	**36Y62H** 15A Socket		**36Y27H** 15A Switched Socket
	**36Y28H** 15A Switched Socket with neon		**36Y30H** French Socket
	**36Y23H** Multi-Function Socket		**36Y24H** Multi-Function Switched Socket
	**36Y22H** 5 Pin Socket		**36Y19H** Double 2 Pin Socket
	**36Y20H** 1G1W+2Pin **36H20AH** 1G2W+2Pin		**36Y21H** 2G1W+2Pin **36Y21AH** 2G2W+2Pin
	**36Y70B** Double USB Charger +13A Socket		**36Y71B** Double USB Charger +Multi-Function Socket

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**36Y37M** USB+2Pin		**36Y34M** Double USB
	**36Y35M** 1G1W+USB **36Y35AM** 1G2W+USB		**36Y36M** 2G1W+USB **36Y36AM** 2G2W+USB
	**36Y46M** TEL Outlet		**36Y47M** PC Outlet
	**36Y50M** Double TEL Outlet		**36Y52M** TEL+ PC Outlet
	**36Y49M** TV+PC Outlet		**36Y48M** TV+TEL Outlet
	**36Y51M** Double PC Outlet		**36Y44M** TV Outlet
	**36Y45M** Satllet Outlet		**36Y31H** Dimmer Speed
	**36Y32H** Dimmer Light		**36Y60H** Dimmer Voice

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	**36Y53H** Voice Light Conrol		**36Y54H** Touch Switch
	**36Y55H** Emergency		**36Y56H** Shaver Socket
	**36Y57H** Card-Insert		**36Y15H** Doorbell Switch
	**36Y63** Corner Light		
	**36L39H** Double 13A Switched Socket		**36L40H** Double 13A Switched Socke with LED
	**36L41H** Double Multi-function Switched Socket		**36L42H** Double Multi-function Switched Socket with LED
	**36L74H** FUSED+Double USB Charger and Multi-Function Socket		**36L77H** Double French Socket
	**36L38H** 5Pin+Double USB		**36L43H** Kitchen Switch



PC Series

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	1 Gang 1 Way Switch **1G1WS PCWW** 1 Gang 2 Way Switch **1G2WS PCWW**		2 Gang 1 Way Switch **2G1WS PCWW** 2 Gang 2 Way Switch **2G2WS PCWW**
	3 Gang 1 Way Switch **3G1WS PCWW** 3 Gang 2 Way Switch **3G2WS PCWW**		4 Gang 1 Way Switch **4G1WS PCWW** 4 Gang 2Way Switch **4G2WS PCWW**
	20A Switch **DP20A PCWW** 45A Switch **DP45A PCWW**		Single Blank Cover **1GBL PCWW** Double Blank Cover **2GBL PCWW**
	13A FUSED Spur Outlet **13AFS PCWW**		13A Socket **13A PCWW**

PROUDCTS PICTURE	MODELS	PROUDCTS PICTURE	MODELS
	13A Switched Socket **13AS PCWW**		13A Switched Socket with Neon **13ASN PCWW**
	16A German Socket **16AG PCWW**		15A UK Socket **15A PCWW**
	15A UK Switched Socket **15AS PCWW**		15A UK Switched Socket with neon **15ASN PCWW**
	16A French Scoket **16AF PCWW**		Universal Switched Socket **UNIS PCWW**
	Universal Switched Socket With Neon **UNISN PCWW**		Universal Socket+ Double Usb **UNIUSB PCWW**
	13a Uk Socket With Double Usb Socket **13AUSB PCWW**		Double USB Socket **2USB PCWW**
	Telphone Socket **PH PCWW**		DATA Socket **DT PCWW**
	Double Telephone Socket **2PH PCWW**		Double DATA Socket **2DT PCWW**
	Telephone + DATA Socket **PHDT PCWW**		TV Socket **TV PCWW**
	Satellite Socket **ST PCWW**		Satellite+ DATA Socket **STDT PCWW**

FUCNTION KEYS (SQUARE)

5 Colors for your chioce:


White color


Grey color


Golden color


Wooden color

POWER SWITCH


11B
1G white


12B
2G white


13B
3G white


14B
4G white


16B
20A white

17B
45A white


58B
Blank white


66B
½ 1G white


67B
½ 2G white

11YB
1G white


12YB
2G white


13YB
3G white



72B
FUSED white


11FJ
1G golden flower


11PJ
1G golden peacock

POWER SOCKET


61H
13A black


25H
13A switched socket black


26H
13A switched socket with neon black


62H
15A switched socket black


27H
15A switched socket black


28H
15A switched socket with neon black


18HY
3 pin socket round black


22H
5 pin black


23H
3 pin switched socket black


24H
3 pin switched socket with neon black



29H
European socket black


30H
French socket black


71B
double USB charger with 3 Pin socket white


70B
double USB charger with 13A socket white


68H
double multi-function switched socket black


69H
double multi-function switched socket black with LED


66H
double 13A switched socket black


67H
double 13A switched socket black with LED


69B
½ 2 pin white

SERVICED CONTROL SWITCH



31H
Speed control black



32H
Light control black



60H
Voice control black

53H
Voice&Light Sensor black

54H
Touch switch black

57H
Card-insert black

56H
Shaver socket black

55H
Emergency black

15H
Doorbell black

14HY
Round doorbell black

DATA OUTLET

47J
PC outlet golden

46J
TEL outlet golden

52J
TEL+PC outlet golden

50J
DoubleTEL outlet golden

51J
Double PC outlet golden

33J
USB charger golden

49J
TV+PC outlet golden

48J
TV+TEL outlet golden

44J
TV outlet golden

45J
Satellite outlet golden

80J
½ USB golden

81J
½ Satellite outlet golden

82J
½ TVoutlet golden

16HY
Round TEL outlet black

17HY
Round PC outlet black

15HY
Round TV outlet black

19HY
Round double TEL outlet black

20HY
Round double PC outlet black

21HY
Round TEL+PC outlet black

FUNCTION PARTS

CRYSTAL SERIES



15BY
86 type white



15HY
86 type black



15XY
86 type champange



15B2
146 type white



15X2
86 type champange



15H2
86 type black



15B
86 type white



15H
86 type black



15X
86 type champange



151B2
146 type white



151X2
86 type champange



151H2
86 type black

SATIN METAL SERIES




26YY
86 type sliver



26JY
86 type golden



26Y
86 type sliver



26J
86 type gloden



26J2
146 type golden



261Y2
146 type sliver



261J2
146 type golden

MIRROR SERIES



25BY
86 type white



25HY
86 type black



25JY
86 type golden



25B2
146 type white



25H2
146 type black



25J2
146 type golden



25B
86 type white



25H
86 type black



25J
86 type golden



251B2
146 type white



251H2
146 type black



251J2
146 type golden

GUNUINE LEATHER SERIES



24EY
86 type crocodile



24ZY
86 type pearl
fish coat



24E
86 type crocodile



24Z
86 type pearl
fish coat



24E2
146 type crocodile



24Z2
146 type pearl
fish coat



241E2
146 type crocodile



241Z2
146 type pearl
fish coat

FUNCTION PARTS

WOODEN SERIES



42Y
86 type log A



42M
86 type log B



42Y2
146 type log A



42M2
146 type log B



421Y2
146 type log A




41Q
86 type artificial wood C



41H
86 type artificial wood D



41Q2
146 type artificial wood C



41H2
146 type artificial wood D



411H2
146 type artificial wood D

SATIN ALUMINIUM SERIES




27Y
86 type sliver



27X
86 type champagne



27Z
86 type brown



27Y2
146 type sliver



27X2
146 type champagne



27Z2
146 type brown

BRONZE SERIES



36L
86 type light bronze



36R
86 type red bronze



36J
86 type golden



36M
86 type metal grey



36Y
86 type matt bronze



36L2
146 type light bronze



36J2
146 type golden



36Y2
146 type matt bronze

LACE SERIES



32H
86 type red bronze



32B
86 type black



32Y
86 type antique



32M
86 type rose golden



32B2
86 type black



32H2
86 type red bronze



321B2
86 type black



321H2
86 type red bronze

FUNCTION PARTS

PALACE SERIES



53QY
86 type bronze




53HY
86 type red bronze



53JY
86 type golden



53J
86 type golden



54H
86 type red bronze



54J
86 type golden



51Y
86 type brass



51M
86 type rose goldden



51W
86 type black bronze



51J
86 type golden



55G
86 type golden



51O2
146 type sliver bronze



51W2
146 type black bronze



51R2
146 type red

PC SERIES



86 type white
PCSW



86 type black
PCSB




86 type golden
PCSG



146 type white
2GPCSW2



146 type black
2GPCSB2



146 type golden
2GPCSG2

Details Make Difference



EXPLODED VIEW DIAGRAM



4 mm Zinc Alloy Panel
Surface treatment by Antioxidant and prevent fingerprint

2. 87mm Zinc Alloy Panel
Zinc alloy material body stamping,never variant

PC fire-retardant insulation layer of panel
Adopt imported PC fire retardant material,
combined with panel in rivet way.

PC fire-retardant functional key panel
imported PC fire retardant materials
High wear resistance performance

High phosphorus copper and fire-retardant flame
copper pieces complete with high precision
phosphor bronze,whose performance is
200 times that of ordinary copper pieces

Medium plate PC fire-retardant mount flame
adopt imported PC fire-retardant materials,
combined with the embedded plate in rivet way

LUMILIFE
ALWAYS CHOOSE SMART

info@lumilife.ae